



## **MASW Training Course** **([Anaheim Marriott](#) – Orange County Ballroom 1)**

### **HANDOUT SUMMARY**

Fundamentals of MASW will be covered in the following topical areas:

- Multichannel Seismic Survey
- Data Acquisition (Active and Passive)
- Data Processing (Dispersion and Inversion)
- Typical Applications
- Practice of Data Processing
- Outdoor Demonstration of Data Acquisition
- In-Class Data Processing with Acquired Data

In addition, in-depth coverage of advanced topics will be included in the following categories:

#### **Dispersion Imaging (Complications and Causes)**

- Why the fundamental mode (M0) is not necessarily the only dominant mode
- When higher modes (M1, M2, etc.) are dominant
- What determines modal energy partitioning
- How multiple modes get mixed together
- Bedrock depth and dispersion images
- Complications from inverse velocity models
- Understanding fundamentals of dispersion imaging
- Computational artifacts from dispersion imaging
- How to extract dispersion curves from complicated image patterns
- Multi-source offset survey and dispersion images
- Methods to process passive data
- Common pitfalls

#### **Inversion Analysis**

- Different Approaches (Pros and Cons):
  - ✓ Traditional fundamental-mode (M0) inversion
  - ✓ Multi-mode inversion (M0, M1, M2, etc.)
  - ✓ Mixed-mode (or apparent mode) inversion
  - ✓ Dispersion image (or phase-velocity spectrum) inversion
  - ✓ Full-waveform inversion
  - ✓ Simple in-field inversion
  - ✓ Inversion of pavement data

- Searching Optimization
  - ✓ Deterministic vs. stochastic approaches
  - ✓ How to optimize the initial velocity model
- Inversion Results
  - ✓ What they represent
  - ✓ What to believe and what not to believe
- Common Pitfalls

### Data Acquisition

- How to determine the critical parameters of source offset ( $X_1$ ), receiver spacing ( $dx$ ), number of channels ( $N_{ch}$ ), and survey interval ( $dSR$ ) for 2-D mapping
- How to choose the optimum receiver
  - ✓ Are low-frequency phones (e.g., 4.5 Hz) really critical?
  - ✓ Can higher-frequency phones (e.g., 14-Hz, 40-Hz, etc.) be used?
- How to choose the optimum source
  - ✓ Sledge hammer (10-lb, 20-lb, etc.) or weight-drop?
- Passive Survey
  - ✓ When and how?
  - ✓ How much gain to expect
- Multi-source offset survey: why and when
- How to handle different bedrock depths
  - ✓ Shallow (e.g.,  $\leq 2m$ ), moderate (e.g.,  $\leq 10m$ ), and deep (e.g.,  $> 10m$ )
- Surveying over pavement
  - ✓ Shadow zone and investigation depth
  - ✓ Differences in acquisition and processing
- Common Pitfalls

### Special Processing

- Back-scattering Analysis of Surface Waves
  - ✓ How it works
  - ✓ Applications
- Common-offset display
  - ✓ What it represents
  - ✓ What different offsets and frequency bands represent

### Common Applications

- Soil/Bedrock Mapping
  - ✓ Wind-turbine site surveys and seismic site classification (1-D survey)
  - ✓ Cross-section geotechnical characterization (2-D survey)
  - ✓ Multiple 2-D surveys and depth slicing (3-D survey)
  - ✓ Evaluation of overburden velocities (S- and P-wave velocities;  $V_s$  and  $V_p$ )
  - ✓ Evaluation of bedrock velocities ( $V_s$  and  $V_p$ )
- Outcrop Surveys (with Little or No Soil)
  - ✓ Differences in data acquisition and analysis
- Anomaly Detection
  - ✓ Void and loose zone mapping by velocity ( $V_s$ ) analysis
  - ✓ Use of back-scattering and common-offset analyses
- Compaction Evaluation by MASW Surveys (CEMS)

- ✓ Application to FDR (Full-Depth Reclamation) pavement construction
- ✓ Application to DDC (Deep Dynamic Compaction)

**Case Studies**

- Actual projects previously performed
  - ✓ Wind-turbine site investigation and seismic site classification (Vs-30m) (1-D Vs profiling)
  - ✓ Overburden/bedrock investigation (2-D Vs cross section)
  - ✓ Anomaly detection (void/sinkhole investigation by surface)